

Localized Capacity (glossary)

Product Systems Engineering Key Aspects > localized capacity

The printable version is no longer supported and may have rendering errors. Please update your browser bookmarks and please use the default browser print function instead.

A design principle that allows a system to degrade gradually upon the encounter with a threat. It assumes that the capability of a system is concentrated in local nodes so that no more than one node fails at a time. -- adapted from (Woods 2006)

Sources

Woods, D.D. 2006. "Essential Characteristics of Resilience." In *Resilience Engineering: Concepts and Precepts*, edited by E. Hollnagel, Woods, D.D., and N. Leveson. Aldershot, UK: Ashgate Publishing Limited.

Discussion

This is a key design principle in the context of resilience to achieve the attribute of tolerance.

SEBoK v. 2.10, released 06 May 2024

Retrieved from

"[https://sandbox.sebokwiki.org/index.php?title=Localized_Capacity_\(glossary\)&oldid=71686](https://sandbox.sebokwiki.org/index.php?title=Localized_Capacity_(glossary)&oldid=71686)"

This page was last edited on 2 May 2024, at 22:57.